

QUICKSTART TABLET

1. CONNECT THE TABLET TO YOUR WI-FI NETWORK



Start "**Settings**" application on your tablet's home screen.


SETTINGS Q (2)		Q (2) CONNECTIONS	CONNECTIONS	
	Connections	W-FI Arson 65 50Hz	•	
40	Sound Sounds, Do not detters	Bluetooth Connect to markly Bluetooth chroasel	9	
8	Notifications Rock along privation	Tablet visibility Allow other devices to first your tablet and transfer files		
ß	Display Reparent Heroit action	Data usage		
	Wallpaper Wallpaper	Flight mode Turn off nativetric frameway, including yes (4) and illustrooms	2	
	Advanced features Multi window	Location Allow ages and services to determine your location.	9	
	Device maintenance Battery Storage, Memory Device security	More connection settings		
	Apps Default apps, App permissions	LOOKING FOR SOMETHING ELSE? SAMSUNG CLOUD		
	Lock screen Serren lock type, Clock style			
Ð	Security Find My Mobile, Secure Finder			

Select "**Connections**" section and click on "**Wi-Fi**". Select your Wi-Fi network.

2. DEVICE APPLICATION LAUNCH




Click on the device icon on your tablet's home screen to launch the application.




Enter your LPG[®] account (email address connected to your LPG[®] account) and password (chosen by yourself). In case of forgotten password, please click on "can't access your account?" or on the following link to reset it: https://password.lpgsystems.net

QUICKSTART TABLET

3. AGREE TO THE LICENSE AGREEMENT



The licence agreement appears. Please scroll down to the bottom and tick the approval boxes. Click on "**Accept**".



You can now use the application.

4. CONNECT YOUR TABLET TO YOUR DEVICE

G HUBER 360" EVOLUTION 11:20	ę			
SETTINGS				
C Date and time				
Language				
Update				
Sound				
Display				
🗢 WIFI				
Head key config				
Tablet				
() System information				
Preferences				

First of all, before connecting your tablet to your device, make sure that:

- Your tablet and your device are connected to the same Wi-Fi network.
- 2 Your HUBER 360° APP is launched. Select "Tablet" item in the "Settings" menu of your device.



Your device automatically detects your tablet. The "**tablet**" icon at the top right corner of your device screen and that of your tablet ensures that the connection is operational.



QUICKSTART TABLET

SAVE AND PROTECT YOUR DATA



For more security, **save all your data on an external support of your choice**: micro SD card (available in supermarkets or in specialized stores), personal

computer^{*}, external hard drive...

At the time of saving^{**}, choose a password for security protection. **Please keep it safe because without it, it will be impossible to restore your backups**. For privacy reasons, LPG SYSTEMS does not have access to your password and cannot ask you for it. LPG SYSTEMS can not be held responsible for any loss of your data.



*Use the USB cable provided with the tablet to connect the tablet to your personal computer. **Go to the HUBER 360 APP settings menu, "Database" section.

NEED HELP ?

Discover our video tutorials for step-by-step guidance in the use of your device. Scan the QR Code below with your phone's or your tablet's camera. You will then be redirected to the corresponding playlist. If the QR Code reading does not work, simply download the free "Unitag" app from the Google Play Store or Apple Store.

Should you have any questions, please contact your local LPG° distributor.

Tél : 04 75 78 69 00 Mail : sav@lpgsystems.com